

Please keep this manual in a safe and handy place for future reference.


## CAUTION

**Read these precautions carefully before you install the key cover.**

These precautions are to promote safe use of the key cover and to prevent injury and damage from occurring to you and others. Following them carefully ensures that you will get long and safe usage from your key cover.

- Be careful not to confuse any of the parts, and be sure to install all parts in the correct direction and according to the sequence given below.
- Assembly should be carried out by at least two persons.
- Use only the screws specified when installing the key cover. Use of any other screws may result in an inadequate installation that may cause damage to both the keyboard and the key cover.
- Do not apply excessive force to the key cover as it may damage the cover.
- Make sure the key cover is sturdy and safe, and all screws have been tight and firm before use. If not, the key cover may drop, or may result in injury to the user.
- To disassemble, reverse the assembly sequence given below.
- Take care that the key cover does not pinch your fingers, and do not insert your finger or hand in any gaps on the key cover or instrument.

Have a Phillips-head (+) screwdriver of the appropriate size ready.



## Assembly Instructions


### 1 Confirm that the key cover is included in the package.

If a music rest is inserted in the instrument, remove it. The key cover also functions as a music rest.

### 2 Remove the cover mounts from the upper left and right of the panel.


#### 2-1 Using a screwdriver, remove the four screws using a screwdriver from the cover mounts.

Do not discard the screws; you'll need them later in step 4.




### 2-2 Remove the cover mounts.

Keep the cover mounts in a safe place for future use.




### 3 Put the key cover in place.

Place the anchors of the key cover into the holes from which you removed cover mounts.



### 4 Install the key cover.

Fix the key cover anchors to the instrument by securely fastening the four screws you removed in step 2-1.



### Post-assembly checklist

Once you've assembled the stand, check the following points:

- **Are there any parts left over?**  
If so, read the assembly instructions again and correct any mistakes you might have made.
- **If the key cover makes a creaking noise or seems unsteady when you play it, refer carefully to the assembly instructions and diagrams and retighten all screws.**