

DIGITAL PIANO

# P-515

---

DATA LIST

DATENLISTE

LISTE DES DONNÉES

LISTA DE DATOS

LISTA DE DADOS

データリスト

XG Voice List..... 2

XG Voice-Liste

Liste des sonorités XG

Lista de sonidos XG

Lista de vozes XG

XG ボイス一覧

Drum Kit List ..... 6

Liste der Drum Kits (Schlagzeug-Sets)

Liste des kits de percussion

Lista del kit de batería

Lista do conjunto de percussão

ドラムキット一覧

# XG Voice List / XG Voice-Liste / Liste des sonorités XG / Lista de sonidos XG / Lista de voces XG / XGボイス一覧

Voice group	Voice name	MSB	LSB	PRG	
PIANO	GrandPiano	0	0	1	
	GrandPiano KSP	0	1	1	
	MellowGndPiano	0	18	1	
	PianoStrings	0	40	1	
	Dream	0	41	1	
	BrightPiano	0	0	2	
	BrightPiano KSP	0	1	2	
	E.GrandPiano	0	0	3	
	E.GndPiano KSP	0	1	3	
	DetunedCP80	0	32	3	
	LayeredCP1	0	40	3	
	LayeredCP2	0	41	3	
	Honkytonk	0	0	4	
	Honkytonk KSP	0	1	4	
	ElectricPiano1	0	0	5	
	E.Piano1 KSP	0	1	5	
	Mellow E.Piano	0	18	5	
	ChorusEP1	0	32	5	
	Hard E.Piano	0	40	5	
	Vxfade E.Piano1	0	45	5	
	60s E.Piano1	0	64	5	
	ElectricPiano2	0	0	6	
	E.Piano2 KSP	0	1	6	
	ChorusEP2	0	32	6	
	DXEPHard	0	33	6	
	DXLegend	0	34	6	
	DXPhaseEP	0	40	6	
	DX+AnalogEP	0	41	6	
	DXKotoEP	0	42	6	
	VXfadeE.Piano2	0	45	6	
	Harpsichord	0	0	7	
	Harpsichord KSP	0	1	7	
	Harpsichord2	0	25	7	
	Harpsichord3	0	35	7	
	Clavi	0	0	8	
	Clavi KSP	0	1	8	
	ClaviWah	0	27	8	
	PulseClavi	0	64	8	
	PierceClavi	0	65	8	
	CHROMATIC PERC.	Celesta	0	0	9
		Glockenspiel	0	0	10
		MusicBox	0	0	11
		MusicBox2	0	64	11
		Vibraphone	0	0	12
		Vibraphone KSP	0	1	12
		HardVibes	0	45	12
		Marimba	0	0	13
		Marimba KSP	0	1	13
		SineMarimba	0	64	13
		Balimba	0	97	13
		LogDrums	0	98	13
		Xylophone	0	0	14
		TubularBells	0	0	15
		ChurchBells	0	96	15
		Carillon	0	97	15
		Dulcimer	0	0	16
		Dulcimer2	0	35	16
Cimbalom		0	96	16	
Santur		0	97	16	
ORGAN		DrawbarOrgan	0	0	17
		DetDrawOrgan	0	32	17
		60sDrawOrgan1	0	33	17
	60sDrawOrgan2	0	34	17	
	70sDrawOrgan1	0	35	17	
	DrawbarOrgan2	0	36	17	
	60sDrawOrgan3	0	37	17	
	EvenBarOrgan	0	38	17	
	16+2'2_3Organ	0	40	17	
	OrganBass	0	64	17	

Voice group	Voice name	MSB	LSB	PRG	
ORGAN	70sDrawOrgan2	0	65	17	
	CheezyOrgan	0	66	17	
	DrawbarOrgan3	0	67	17	
	Perc.Organ1	0	0	18	
	70sPerc.Organ1	0	24	18	
	DetPerc.Organ	0	32	18	
	LightOrgan	0	33	18	
	Perc.Organ2	0	37	18	
	RockOrgan	0	0	19	
	RotaryOrgan	0	64	19	
	SlowRotary	0	65	19	
	FastRotary	0	66	19	
	ChurchOrgan	0	0	20	
	ChurchOrgan3	0	32	20	
	ChurchOrgan2	0	35	20	
	NotreDame	0	40	20	
	OrganFlute	0	64	20	
	Trem.OrganFlute	0	65	20	
	ReedOrgan	0	0	21	
	PuffOrgan	0	40	21	
	Accordion	0	0	22	
	AccordionItalian	0	32	22	
	Harmonica	0	0	23	
	Harmonica2	0	32	23	
TangoAccordion	0	0	24		
TangoAccord2	0	64	24		
GUITAR	NylonGuitar	0	0	25	
	NylonGuitar2	0	16	25	
	NylonGuitar3	0	25	25	
	VelocityGtrHarmo	0	43	25	
	Ukulele	0	96	25	
	SteelGuitar	0	0	26	
	SteelGuitar2	0	16	26	
	12StrGuitar	0	35	26	
	Nylon&Steel	0	40	26	
	Steel&Body	0	41	26	
	Mandolin	0	96	26	
	JazzGuitar	0	0	27	
	MellowGuitar	0	18	27	
	JazzAmp	0	32	27	
	CleanGuitar	0	0	28	
	ChorusGuitar	0	32	28	
	MutedGuitar	0	0	29	
	FunkGuitar1	0	40	29	
	MuteSteelGuitar	0	41	29	
	FunkGuitar2	0	43	29	
	JazzMan	0	45	29	
	Overdriven	0	0	30	
	GuitarPinch	0	43	30	
	DistortionGuitar	0	0	31	
	FeedbackGuitar	0	40	31	
	FeedbackGtr2	0	41	31	
	GuitarHarmonics	0	0	32	
	GuitarFeedback	0	65	32	
	GuitarHarmonic2	0	66	32	
	BASS	AcousticBass	0	0	33
		JazzRhythm	0	40	33
		VXUprghntBass	0	45	33
FingerBass		0	0	34	
FingerBassDark		0	18	34	
FlangeBass		0	27	34	
Bass&DistEG		0	40	34	
FingerSlapBass		0	43	34	
FingerBass2		0	45	34	
ModulatedBass		0	65	34	
PickBass		0	0	35	
MutePickBass		0	28	35	
FretlessBass		0	0	36	
FretlessBass2		0	32	36	

Voice group	Voice name	MSB	LSB	PRG	
BASS	FretlessBass3	0	33	36	
	FretlessBass4	0	34	36	
	SynthFretless	0	96	36	
	SmthFretless	0	97	36	
	SlapBass1	0	0	37	
	ResonantSlap	0	27	37	
	PunchThumb	0	32	37	
	SlapBass2	0	0	38	
	VeloSwitchSlap	0	43	38	
	SynthBass1	0	0	39	
	SynthBass1Dark	0	18	39	
	FastResoBass	0	20	39	
	AcidBass	0	24	39	
	ClaviBass	0	35	39	
	TechnoBass	0	40	39	
	Orbiter	0	64	39	
	SquareBass	0	65	39	
	RubberBass	0	66	39	
	Hammer	0	96	39	
	SynthBass2	0	0	40	
	MellowSynBass	0	6	40	
	SequenceBass	0	12	40	
	ClickSynthBass	0	18	40	
	SynthBass2Dark	0	19	40	
	SmoothSynBass	0	32	40	
	ModulrSynBass	0	40	40	
	DXBass	0	41	40	
	XWireBass	0	64	40	
	STRINGS	Violin	0	0	41
		SlowAttackViolin	0	8	41
		Viola	0	0	42
		Cello	0	0	43
		Contrabass	0	0	44
		TremoloStrings	0	0	45
		SlwAtkTremStr	0	8	45
		SuspenseStrings	0	40	45
		PizzicatoStrings	0	0	46
		OrchestralHarp	0	0	47
		YangQin	0	40	47
		Timpani	0	0	48
ENSEMBLE		Strings1	0	0	49
		StereoStrings	0	3	49
	SlwAtkStrings	0	8	49	
	ArcoSStrings	0	24	49	
	60sStrings	0	35	49	
	Orchestra	0	40	49	
	Orchestra2	0	41	49	
	TremoloOrchestra	0	42	49	
	VelocityStrings	0	45	49	
	Strings2	0	0	50	
	StereoSlwStrings	0	3	50	
	LegatoStrings	0	8	50	
	WarmStrings	0	40	50	
	Kingdom	0	41	50	
	70sStrings	0	64	50	
	Strings3	0	65	50	
	SynthStrings1	0	0	51	
	ResonantStrings	0	27	51	
	SynthStrings4	0	64	51	
	SynthStrings5	0	65	51	
	SynthStrings2	0	0	52	
	ChoirAahs	0	0	53	
	StereoChoir	0	3	53	
	ChoirAahs2	0	16	53	
	MellowChoir	0	32	53	
	ChoirStrings	0	40	53	
	VoiceOohs	0	0	54	
	SynthVoice	0	0	55	
	SynthVoice2	0	40	55	

Voice group	Voice name	MSB	LSB	PRG	
ENSEMBLE	Choral	0	41	55	
	AnalogVoice	0	64	55	
	OrchestraHit	0	0	56	
	OrchestraHit2	0	35	56	
	Impact	0	64	56	
	BRASS	Trumpet	0	0	57
Trumpet2		0	16	57	
BrightTrumpet		0	17	57	
WarmTrumpet		0	32	57	
Trombone		0	0	58	
Trombone2		0	18	58	
Tuba		0	0	59	
Tuba2		0	16	59	
MutedTrumpet		0	0	60	
FrenchHorn		0	0	61	
FrenchHornSolo		0	6	61	
FrenchHorn2		0	32	61	
HornOrchestra		0	37	61	
BrassSection		0	0	62	
Tp&TbSection		0	35	62	
BrassSection2		0	40	62	
HighBrass		0	41	62	
MellowBrass		0	42	62	
SynthBrass1		0	0	63	
QuackBrass		0	12	63	
ResoSynthBrass		0	20	63	
PolyBrass		0	24	63	
SynthBrass3		0	27	63	
JumpBrass		0	32	63	
An.VeloBrass1		0	45	63	
AnalogBrass1		0	64	63	
SynthBrass2		0	0	64	
SoftBrass		0	18	64	
SynthBrass4		0	40	64	
ChoirBrass		0	41	64	
An.VeloBrass2		0	45	64	
AnalogBrass2		0	64	64	
REED		SopranoSax	0	0	65
		AltoSax	0	0	66
		SaxSection	0	40	66
		HyperAltoSax	0	43	66
		TenorSax	0	0	67
		BreathyTenor	0	40	67
		SoftTenorSax	0	41	67
		TenorSax2	0	64	67
	BaritoneSax	0	0	68	
	Oboe	0	0	69	
	EnglishHorn	0	0	70	
	Bassoon	0	0	71	
	Clarinet	0	0	72	
	PIPE	Piccolo	0	0	73
Flute		0	0	74	
Recorder		0	0	75	
PanFlute		0	0	76	
BlownBottle		0	0	77	
Shakuhachi		0	0	78	
Whistle		0	0	79	
Ocarina		0	0	80	
SYNTH LEAD		SquareLead	0	0	81
		SquareLead2	0	6	81
	LMSquare	0	8	81	
	Hollow	0	18	81	
	Shroud	0	19	81	
	Mellow	0	64	81	
	SoloSine	0	65	81	
	SineLead	0	66	81	
	SawtoothLead	0	0	82	
	SawtoothLead2	0	6	82	
ThickSaw	0	8	82		

Voice group	Voice name	MSB	LSB	PRG	
SYNTH LEAD	DynamicSaw	0	18	82	
	DigitalSaw	0	19	82	
	BigLead	0	20	82	
	HeavySynth	0	24	82	
	WaspySynth	0	25	82	
	PulseSaw	0	40	82	
	Dr.Lead	0	41	82	
	VelocityLead	0	45	82	
	SequenceAnalog	0	96	82	
	CalliopeLead	0	0	83	
	PureLead	0	65	83	
	ChiffLead	0	0	84	
	Rubby	0	64	84	
	CharangLead	0	0	85	
	DistortedLead	0	64	85	
	WireLead	0	65	85	
	VoiceLead	0	0	86	
	SynthAahs	0	24	86	
	VoxLead	0	64	86	
	FifthsLead	0	0	87	
	BigFive	0	35	87	
	Bass&Lead	0	0	88	
	Big&Low	0	16	88	
	Fat&Perky	0	64	88	
SoftWhirl	0	65	88		
SYNTH PAD	NewAgePad	0	0	89	
	Fantasy	0	64	89	
	WarmPad	0	0	90	
	ThickPad	0	16	90	
	SoftPad	0	17	90	
	SinePad	0	18	90	
	HornPad	0	64	90	
	RotaryStrings	0	65	90	
	PolySynthPad	0	0	91	
	PolyPad80	0	64	91	
	ClickPad	0	65	91	
	AnalogPad	0	66	91	
	SquarePad	0	67	91	
	ChoirPad	0	0	92	
	Heaven	0	64	92	
	Itopia	0	66	92	
	CCPad	0	67	92	
	BowedPad	0	0	93	
	Glacier	0	64	93	
	GlassPad	0	65	93	
	MetallicPad	0	0	94	
	TinePad	0	64	94	
	PanPad	0	65	94	
	HaloPad	0	0	95	
	SweepPad	0	0	96	
	Shwimmer	0	20	96	
	Converge	0	27	96	
	PolarPad	0	64	96	
	Celestial	0	66	96	
	SYNTH EFFECTS	Rain	0	0	97
		ClaviPad	0	45	97
		HarmoRain	0	64	97
AfricanWind		0	65	97	
Carib		0	66	97	
SoundTrack		0	0	98	
Prologue		0	27	98	
Ancestral		0	64	98	
Crystal		0	0	99	
SynthDrumComp		0	12	99	
Popcorn		0	14	99	
TinyBells		0	18	99	
RoundGlocken		0	35	99	
GlockenChime		0	40	99	
ClearBells		0	41	99	

Voice group	Voice name	MSB	LSB	PRG
SYNTH EFFECTS	ChorusBells	0	42	99
	SynthMallet	0	64	99
	SoftCrystal	0	65	99
	LoudGlocken	0	66	99
	ChristmasBells	0	67	99
	VibraphoneBells	0	68	99
	DigitalBells	0	69	99
	AirBells	0	70	99
	BellHarp	0	71	99
	Gamelimba	0	72	99
	Atmosphere	0	0	100
	WarmAtmos.	0	18	100
	HolwRelease	0	19	100
	NylonEl.Piano	0	40	100
	NylonHarp	0	64	100
	HarpVox	0	65	100
	AtmospherePad	0	66	100
	Planet	0	67	100
	Brightness	0	0	101
	FantasyBells	0	64	101
	Smokey	0	96	101
	Goblins	0	0	102
	GoblinsSynth	0	64	102
	Creeper	0	65	102
	RingPad	0	66	102
	Ritual	0	67	102
	ToHeaven	0	68	102
	Night	0	70	102
	Glisten	0	71	102
	BellChoir	0	96	102
	Echoes	0	0	103
	Echoes2	0	8	103
	EchoPan	0	14	103
	EchoBells	0	64	103
BigPan	0	65	103	
SynthPiano	0	66	103	
Creation	0	67	103	
Stardust	0	68	103	
Reso&Panning	0	69	103	
ScienceFiction	0	0	104	
Starz	0	64	104	
ETHNIC	Sitar	0	0	105
	DetunedSitar	0	32	105
	Sitar2	0	35	105
	Tambra	0	96	105
	Tamboura	0	97	105
	Banjo	0	0	106
	MutedBanjo	0	28	106
	Rabab	0	96	106
	Gopichant	0	97	106
	Oud	0	98	106
	Shamisen	0	0	107
	Koto	0	0	108
	Taisho-kin	0	96	108
	Kanoon	0	97	108
	Kalimba	0	0	109
	Bagpipe	0	0	110
	Fiddle	0	0	111
	Shanai	0	0	112
Shanai2	0	64	112	
Pungi	0	96	112	
Hichiriki	0	97	112	
PERCUSSIVE	TinkleBell	0	0	113
	Bonang	0	96	113
	Altair	0	97	113
	GamelanGongs	0	98	113
	StereoGamelan	0	99	113
	RamaCymbal	0	100	113
AsianBells	0	101	113	

Voice group	Voice name	MSB	LSB	PRG
PERCUSSIVE	Agogo	0	0	114
	SteelDrums	0	0	115
	GlassPercussion	0	97	115
	ThaiBells	0	98	115
	Woodblock	0	0	116
	Castanets	0	96	116
	TaikoDrum	0	0	117
	GranCassa	0	96	117
	MelodicTom	0	0	118
	MelodicTom2	0	64	118
	RealTom	0	65	118
	RockTom	0	66	118
	SynthDrum	0	0	119
	AnalogTom	0	64	119
ElectroPerc.	0	65	119	
ReverseCymbal	0	0	120	
SOUND EFFECTS	GuitarFretNoise	0	0	121
	BreathNoise	0	0	122
	Seashore	0	0	123
	BirdTweet	0	0	124
	TelephoneRing	0	0	125
	Helicopter	0	0	126
	Applause	0	0	127
	Gunshot	0	0	128
SFX	CuttingNoise	64	0	1
	CuttingNoise2	64	0	2
	StringSlap	64	0	4
	FluteKeyClick	64	0	17
	Shower	64	0	33
	Thunder	64	0	34
	Wind	64	0	35
	Stream	64	0	36
	Bubble	64	0	37
	Feed	64	0	38
	Dog	64	0	49
	Horse	64	0	50
	BirdTweet2	64	0	51
	Ghost	64	0	55
	Maou	64	0	56
	PhoneCall	64	0	65
	DoorSqueak	64	0	66
	DoorSlam	64	0	67
	ScratchCut	64	0	68
	ScratchSplit	64	0	69
	WindChime	64	0	70
	TelephoneRing2	64	0	71
	CarEngineIgn	64	0	81
	CarTiresSquel	64	0	82
	CarPassing	64	0	83
	CarCrash	64	0	84
	Siren	64	0	85
	Train	64	0	86
	JetPlane	64	0	87
	Starship	64	0	88
	Burst	64	0	89
	RollerCoaster	64	0	90
	Submarine	64	0	91
	Laugh	64	0	97
Scream	64	0	98	
Punch	64	0	99	
Heartbeat	64	0	100	
FootSteps	64	0	101	
MachineGun	64	0	113	
LaserGun	64	0	114	
Explosion	64	0	115	
Firework	64	0	116	

# Drum Kit List / Liste der Drum Kits (Schlagzeug-Sets) / Liste des kits de percussion / Lista del kit de batería / Lista do conjunto de percussão / ドラムキット一覧

Kit Name		Standard Kit 1			Standard Kit 2			Room Kit			Rock Kit			Electro Kit		
MSB-LSB-PC# (Org: 1)		127-0-1			127-0-2			127-0-9			127-0-17			127-0-25		
Note#	MIDI Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3
14	D-1	Surdo Open		3	Surdo Open		3	Surdo Open		3	Surdo Open		3	Surdo Open		3
15	D#-1	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	Whip Slap			Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	Scratch H		4	Scratch H		4	Scratch H		4	Scratch H		4	Scratch H		4
18	F#-1	Scratch L		4	Scratch L		4	Scratch L		4	Scratch L		4	Scratch L		4
19	G-1	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	Metronome Click			Metronome Click			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	Seq Click L			Seq Click L			Seq Click L			Seq Click L			Seq Click L		
24	C0	Seq Click H			Seq Click H			Seq Click H			Seq Click H			Seq Click H		
25	C#0	Brush Tap			Brush Tap			Brush Tap			Brush Tap			Brush Tap		
26	D0	Brush Swirl	●		Brush Swirl	●		Brush Swirl	●		Brush Swirl	●		Brush Swirl	●	
27	D#0	Brush Slap			Brush Slap			Brush Slap			Brush Slap			Brush Slap		
28	E0	Brush Tap Swirl	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Reverse Cymbal	●	
29	F0	Snare Roll	●		Snare Roll	●		Snare Roll	●		Snare Roll	●		Snare Roll	●	
30	F#0	Castanet			Castanet			Castanet			Castanet			Hi Q 2		
31	G0	Snare Soft			Snare Soft 2			Snare Soft			Snare Noisy			Snare Snappy Electro		
32	G#0	Sticks			Sticks			Sticks			Sticks			Sticks		
33	A0	Kick Soft			Kick Soft			Kick Soft			Kick Soft			Kick 3		
34	A#0	Open Rim Shot			Open Rim Shot H Short			Open Rim Shot			Open Rim Shot			Open Rim Shot		
35	B0	Kick Tight			Kick Tight			Kick Tight			Kick 2			Kick Gate		
36	C1	Kick			Kick Short			Kick			Kick Gate			Kick Gate Heavy		
37	C#1	Side Stick			Side Stick Light			Side Stick			Side Stick			Side Stick		
38	D1	Snare			Snare Short			Snare Snappy			Snare Rock			Snare Noisy 2		
39	D#1	Hand Clap			Hand Clap			Hand Clap			Hand Clap			Hand Clap		
40	E1	Snare Tight			Snare Tight H			Snare Tight Snappy			Snare Rock Tight			Snare Noisy 3		
41	F1	Floor Tom L			Floor Tom L			Tom Room 1			Tom Rock 1			Tom Electro 1		
42	F#1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed		1
43	G1	Floor Tom H			Floor Tom H			Tom Room 2			Tom Rock 2			Tom Electro 2		
44	G#1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1
45	A1	Low Tom			Low Tom			Tom Room 3			Tom Rock 3			Tom Electro 3		
46	A#1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open		1
47	B1	Mid Tom L			Mid Tom L			Tom Room 4			Tom Rock 4			Tom Electro 4		
48	C2	Mid Tom H			Mid Tom H			Tom Room 5			Tom Rock 5			Tom Electro 5		
49	C#2	Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1		
50	D2	High Tom			High Tom			Tom Room 6			Tom Rock 6			Tom Electro 6		
51	D#2	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1		
52	E2	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			Chinese Cymbal		
53	F2	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup		
54	F#2	Tambourine			Tambourine			Tambourine			Tambourine			Tambourine		
55	G2	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal		
56	G#2	Cowbell			Cowbell			Cowbell			Cowbell			Cowbell		
57	A2	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2		
58	A#2	Vibraslap			Vibraslap			Vibraslap			Vibraslap			Vibraslap		
59	B2	Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2		
60	C3	Bongo H			Bongo H			Bongo H			Bongo H			Bongo H		
61	C#3	Bongo L			Bongo L			Bongo L			Bongo L			Bongo L		
62	D3	Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	Conga H Open			Conga H Open			Conga H Open			Conga H Open			Conga H Open		
64	E3	Conga L			Conga L			Conga L			Conga L			Conga L		
65	F3	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	Maracas			Maracas			Maracas			Maracas			Maracas		
71	B3	Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●	
72	C4	Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●	
73	C#4	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●	
75	D#4	Claves			Claves			Claves			Claves			Claves		
76	E4	Wood Block H			Wood Block H			Wood Block H			Wood Block H			Wood Block H		
77	F4	Wood Block L			Wood Block L			Wood Block L			Wood Block L			Wood Block L		
78	F#4	Cuica Mute			Cuica Mute			Cuica Mute			Cuica Mute			Scratch H 2		
79	G4	Cuica Open			Cuica Open			Cuica Open			Cuica Open			Scratch L 2		
80	G#4	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2
81	A4	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2
82	A#4	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	Bell Tree			Bell Tree			Bell Tree			Bell Tree			Bell Tree		
85	C#5															
86	D5															
87	D#5															
88	E5															
89	F5															
90	F#5															
91	G5															

Same as Standard Kit 1  
Standard Kit 1と同じ  
No Sound  
音は鳴りません

\*1 Key Off: Keys marked \*●\* stop sounding the instant they are released.

\*1 Key Off 属性に (●) がついている楽器は、鍵盤を離したとき発音が止まります。

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

\*2 Alt Grp (Alternate Group) 欄の番号はグループを表し、同じグループ番号の中で、1つの楽器を発音させると同じグループの中の他の楽器の発音が止まります。

Kit Name		Analog Kit			Dance Kit			Jazz Kit			Brush Kit			Real Brushes		
MSB-LSB-PC# (Org:1)		127-0-26			127-0-28			127-0-33			127-0-41			127-0-42		
Note#	MIDI Note	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	Surdo Mute		3	Kick Dance 1			Surdo Mute		3	Surdo Mute		3	Surdo Mute		3
14	D-1	Surdo Open		3	Kick Dance 2			Surdo Open		3	Surdo Open		3	Surdo Open		3
15	D#-1	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	Whip Slap			Whip Slap	●		Whip Slap			Whip Slap			Whip Slap		
17	F-1	Scratch H		4	Scratch Dance 1	●		Scratch H		4	Scratch H		4	Scratch H		4
18	F#-1	Scratch L		4	Scratch Dance 2	●		Scratch L		4	Scratch L		4	Scratch L		4
19	G-1	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	Metronome Click			Dance Perc 1			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	Metronome Bell			Reverse Dance 1			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	Seq Click L			Dance Perc 2			Seq Click L			Seq Click L			Seq Click L		
24	C0	Seq Click H			Hi Q Dance 1			Seq Click H			Seq Click H			Vintage Swirl 1	●	
25	C#0	Brush Tap			Snare Analog 3			Brush Tap			Brush Tap			Vintage Slap 1		
26	D0	Brush Swirl	●		Vinyl Noise	●		Brush Swirl	●		Brush Swirl	●		Vintage Swirl 2	●	
27	D#0	Brush Slap			Snare Analog 4			Brush Slap			Brush Slap			Vintage Slap 2		
28	E0	Reverse Cymbal	●		Reverse Cymbal	●		Brush Tap Swirl	●		Brush Tap Swirl	●		Vintage Tap Swirl	●	
29	F0	Snare Roll	●		Reverse Dance 2	●		Snare Roll	●		Snare Roll	●		Vintage Slap Swirl	●	
30	F#0	Hi Q 2			Hi Q 2			Castanet			Castanet			Vintage Swirl 3	●	
31	G0	Snare Noisy 4			Snare Techno			Snare Jazz H			Brush Slap 2			Vintage Slap 3		
32	G#0	Sticks			Snare Dance 1			Sticks			Sticks			Sticks		
33	A0	Kick 3			Kick Techno Q			Kick Soft			Kick Soft			Kick Soft L		
34	A#0	Open Rim Shot			Rim Gate			Open Rim Shot			Open Rim Shot			Open Rim Shot Real Brushes		
35	B0	Kick Analog Short			Kick Techno L			Kick Tight			Kick Tight			Kick Soft H		
36	C1	Kick Analog			Kick Techno			Kick Jazz			Kick Jazz			Kick Jazz Ambience		
37	C#1	Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Light			Side Stick Real Brushes		
38	D1	Snare Analog			Snare Clap			Snare Jazz L			Brush Slap 3			Vintage Slap 4		
39	D#1	Hand Clap			Dance Clap			Hand Clap			Hand Clap			Clap Power		
40	E1	Snare Analog 2			Snare Dry			Snare Jazz M			Brush Tap 2			Vintage Slap 5		
41	F1	Tom Analog 1			Tom Dance 1			Floor Tom L			Tom Brush 1			Tom Real Brushes 1		
42	F#1	Hi-Hat Closed Analog		1	Hi-Hat Closed 3		1	Hi-Hat Closed		1	Hi-Hat Closed		1	Hi-Hat Closed Real Brushes		1
43	G1	Tom Analog 2			Tom Dance 2			Floor Tom H			Tom Brush 2			Tom Real Brushes 2		
44	G#1	Hi-Hat Closed Analog 2		1	Hi-Hat Closed Analog 3		1	Hi-Hat Pedal		1	Hi-Hat Pedal		1	Hi-Hat Pedal Real Brushes		1
45	A1	Tom Analog 3			Tom Dance 3			Low Tom			Tom Brush 3			Tom Real Brushes 3		
46	A#1	Hi-Hat Open Analog		1	Hi-Hat Open 3		1	Hi-Hat Open		1	Hi-Hat Open		1	Hi-Hat Open Real Brushes		1
47	B1	Tom Analog 4			Tom Dance 4			Mid Tom L			Tom Brush 4			Tom Real Brushes 4		
48	C2	Tom Analog 5			Tom Dance 5			Mid Tom H			Tom Brush 5			Tom Real Brushes 5		
49	C#2	Crash Analog			Crash Analog			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal Real Brushes 1		
50	D2	Tom Analog 6			Tom Dance 6			High Tom			Tom Brush 6			Tom Real Brushes 6		
51	D#2	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal Real Brushes		
52	E2	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			China Cymbal			China Cymbal Real Brushes		
53	F2	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cup Real Brushes 1		
54	F#2	Tambourine			Tambourine Analog			Tambourine			Tambourine			Tambourine		
55	G2	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal Real Brushes		
56	G#2	Cowbell Analog			Cowbell Dance			Cowbell			Cowbell			Cowbell		
57	A2	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal Real Brushes 2		
58	A#2	Vibraslap			Vibraslap Analog			Vibraslap			Vibraslap			Vibraslap		
59	B2	Ride Cymbal 2			Ride Analog			Ride Cymbal 2			Ride Cymbal 2			Ride Cup Real Brushes 2		
60	C3	Bongo H			Bongo Analog H			Bongo H			Bongo H			Bongo H		
61	C#3	Bongo L			Bongo Analog L			Bongo L			Bongo L			Bongo L		
62	D3	Conga Analog H			Conga Analog H			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	Conga Analog M			Conga Analog M			Conga H Open			Conga H Open			Conga H Open		
64	E3	Conga Analog L			Conga Analog L			Conga L			Conga L			Conga L		
65	F3	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	Maracas 2			Maracas 2			Maracas			Maracas			Maracas		
71	B3	Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●		Samba Whistle H	●	
72	C4	Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●		Samba Whistle L	●	
73	C#4	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●		Guiro Long	●	
75	D#4	Claves 2			Claves 2			Claves			Claves			Claves		
76	E4	Wood Block H			Dance Perc 3			Wood Block H			Wood Block H			Wood Block H		
77	F4	Wood Block L			Dance Perc 4	●		Wood Block L			Wood Block L			Wood Block L		
78	F#4	Scratch H 2			Dance Breath 1			Cuica Mute			Cuica Mute			Cuica Mute		
79	G4	Scratch L 2			Dance Breath 2	●		Cuica Open			Cuica Open			Cuica Open		
80	G#4	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2	Triangle Mute		2
81	A4	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2	Triangle Open		2
82	A#4	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	Bell Tree			Bell Tree			Bell Tree			Bell Tree			Wind Chime		
85	C#5															
86	D5															
87	D#5															
88	E5															
89	F5															
90	F#5															
91	G5															

Kit Name		Symphony Kit			Hip Hop Kit			Break Kit			Power Kit			Real Drums		
MSB-LSB-PC# (Org:1)		127-0-49			127-0-57			127-0-58			127-0-88			127-0-92		
Note#	MIDI Note	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	Surdo Mute		3	Surdo Mute		5	Surdo Mute		3	Surdo Mute		3	Surdo Mute		3
14	D-1	Surdo Open		3	Surdo Open		5	Surdo Open		3	Surdo Open		3	Surdo Open		3
15	D#-1	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	Whip Slap			Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	Scratch H		4	Scratch H		6	Scratch H		4	Scratch H		4	Scratch H		4
18	F#-1	Scratch L		4	Scratch L		6	Scratch L		4	Scratch L		4	Scratch L		4
19	G-1	Finger Snap			Hi-Hat Closed T8 2		4	Finger Snap			Finger Snap			Finger Snap		
20	G#-1	Click Noise			Tom T8 3			Snare Break 8			Click Noise			Click Noise		
21	A-1	Metronome Click			Hi-Hat Open T8 2		4	Snare Break 9			Metronome Click			Metronome Click		
22	A#-1	Metronome Bell			Tom T8 6			Hi-Hat Closed Break 1		●	Metronome Bell			Metronome Bell		
23	B-1	Seq Click L			Crash T8			Hi-Hat Closed Break 2		●	Seq Click L			Seq Click L		
24	C0	Seq Click H			Triangle Mute		1	Kick Break Deep			Seq Click H			Seq Click H		
25	C#0	Brush Tap			Triangle Open		1	Snare Hip			Brush Tap			Brush Tap		
26	D0	Brush Swirl		●	Wind Chime			Snare Lo-Fi			Brush Swirl		●	Brush Tap Swirl		●
27	D#0	Brush Slap			Tambourine Light 2			Snare Clappy			Brush Slap			Brush Slap		
28	E0	Brush Tap Swirl		●	Tambourine Light 1			Snare LdwH Mono			Brush Tap Swirl		●	Brush Tap Swirl		●
29	F0	Snare Roll		●	Kick HipHop 9			Snare Rock Roll		●	Snare Roll		●	Snare Roll Rock		●
30	F#0	Castanet			Hi-Hat Closed Tek		3	Snare Gate 1			Castanet			Castanet		
31	G0	Snare Soft			Kick Gate			Snare Mid			Snare Soft Power 1			Snare Tight		
32	G#0	Sticks			Hi-Hat Open Lo-Fi		3	Snare Break Rim			Sticks			Sticks		
33	A0	Kick Soft 2			Kick Gran Casa Open			Kick Break Heavy			Kick Ambient+			Kick Genuine		
34	A#0	Open Rim Shot			Hi-Hat Reverse Drum&Bass			Snare Hip Rim 4			Open Rim Power 1			Rim Real		
35	B0	Gran Cassa			Kick HipHop 1			Kick Break 2			Kick Power Open			Kick Real 1		
36	C1	Gran Cassa Mute			Kick Analog CR			Kick Break 1			Kick Power Mute			Kick Real 2		
37	C#1	Side Stick			Snare Analog Sm Rim			Snare Hip Rim 1			Side Stick Power			Stick Real		
38	D1	Band Snare			Snare HipHop 1			Snare Break 3			Snare Power 1			Snare Real 1		
39	D#1	Hand Clap			Snare Clappy			Snare Break 1			Hand Clap Power			Clap Power		
40	E1	Band Snare 2			Snare HipHop 2			Snare Break 2			Snare Rough			Snare Real 2		
41	F1	Floor Tom L			Floor Tom L			Tom Break 1			Tom Power 1			Tom Real 1		
42	F#1	Hi-Hat Closed		1	Hi-Hat Closed HipHop		2	Hi-Hat Closed Rock Soft		1	Hi-Hat Closed Power		1	Hi-Hat Closed Real		1
43	G1	Floor Tom H			Low Tom			Tom Break 2			Tom Power 2			Tom Real 2		
44	G#1	Hi-Hat Pedal		1	Hi-Hat Pedal HipHop		2	Hi-Hat Pedal Rock		1	Hi-Hat Pedal Power		1	Hi-Hat Pedal Real		1
45	A1	Low Tom			Mid Tom L			Tom Break 3			Tom Power 3			Tom Real 3		
46	A#1	Hi-Hat Open		1	Hi-Hat Open HipHop		2	Hi-Hat Half Open Rock		1	Hi-Hat Open Power		1	Hi-Hat Open Real		1
47	B1	Mid Tom L			High Tom			Tom Break 4			Tom Power 4			Tom Real 4		
48	C2	Mid Tom H			Ride Cymbal 3			Tom Break 5			Tom Power 5			Tom Real 5		
49	C#2	Hand Cymbal			Crash Cymbal 3			Crash Cymbal 1			Crash Cymbal Acoustic 1			Crash Cymbal Real 1		
50	D2	High Tom			Shaker 2			Tom Break 6			Tom Power 6			Tom Real 6		
51	D#2	Hand Cymbal Short			Scratch Bass Drum Forward			Ride Cymbal 3			Ride Cymbal Acoustic 1			Ride Cymbal Real 1		
52	E2	Chinese Cymbal			Scratch Bass Drum Reverse			China Cymbal 2			China Cymbal Acoustic			China Cymbal Real		
53	F2	Ride Cymbal Cup			Kick HipHop 2			Ride Cymbal Cup 2			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Real		
54	F#2	Tambourine			Snare HipHop Rim 2			Tambourine 1 Hit			Tambourine			Tambourine		
55	G2	Splash Cymbal			HipHop Clap 2			Splash Cymbal 2			Splash Cymbal Acoustic			Splash Cymbal Real		
56	G#2	Cowbell			HipHop Snap 1			Cowbell 1			Cowbell			Cowbell		
57	A2	Hand Cymbal 2			Snare HipHop 3			Crash Cymbal 2			Crash Cymbal Acoustic 2			Crash Cymbal Real 2		
58	A#2	Vibraslap			Electric Clap 2			Cowbell RX11			Vibraslap			Vibraslap		
59	B2	Hand Cymbal Short 2			Kick Hip Deep			Ride Cymbal 2			Ride Cymbal Acoustic 2			Ride Cymbal Real 2		
60	C3	Bongo H			Kick HipHop 3			Bongo H			Bongo H			Bongo H		
61	C#3	Bongo L			Snare HipHop Rim 3			Bongo L			Bongo L			Bongo L		
62	D3	Conga H Mute			Snare HipHop 5			Conga H Tip			Conga H Mute			Conga H Mute		
63	D#3	Conga H Open			Electric Clap 1			Conga H Open Slap			Conga H Open			Conga H Open		
64	E3	Conga L			Handbell H			Conga H Open			Conga L			Conga L		
65	F3	Timbale H			Kick HipHop 4			Bongo 2 H			Timbale H			Timbale H		
66	F#3	Timbale L			HipHop Clap 3			Bongo 2 L			Timbale L			Timbale L		
67	G3	Agogo H			HipHop Snap 2			Conga Open			Agogo H			Agogo H		
68	G#3	Agogo L			Snare HipHop Rim 5			Agogo L			Agogo L			Agogo L		
69	A3	Cabasa			HipHop Flex 1			Cabasa			Cabasa			Cabasa		
70	A#3	Maracas			HipHop Flex 2			Maracas Stur			Maracas			Maracas		
71	B3	Samba Whistle H		●	Shaker 2			Timbale H			Samba Whistle H		●	Samba Whistle H		●
72	C4	Samba Whistle L		●	Kick HipHop 5			Timbale L			Samba Whistle L		●	Samba Whistle L		●
73	C#4	Guiro Short			Snare HipHop Rim 4			Scratch H 3		●	Guiro Short			Guiro Short		
74	D4	Guiro Long		●	Snare HipHop 6			Scratch Down		●	Guiro Long		●	Guiro Long		●
75	D#4	Claves			Snare HipHop 11			Claves			Claves			Claves		
76	E4	Wood Block H			Kick HipHop 10			Wood Block H			Wood Block H			Wood Block H		
77	F4	Wood Block L			Snare HipHop 7			Wood Block L			Wood Block L			Wood Block L		
78	F#4	Cuica Mute			HipHop Clap 5			Scratch H 2			Cuica Mute			Cuica Mute		
79	G4	Cuica Open			Conga H Tip			Scratch L 2			Cuica Open			Cuica Open		
80	G#4	Triangle Mute		2	Conga H Heel			Triangle Mute		2	Triangle Mute		2	Triangle Mute		2
81	A4	Triangle Open		2	Conga H Open			Triangle Open		2	Triangle Open		2	Triangle Open		2
82	A#4	Shaker			Conga L Open 1			Kick Break 3			Shaker			Shaker		
83	B4	Jingle Bells			Conga L Open 2			Kick Break 4			Jingle Bells			Jingle Bells		
84	C5	Bell Tree			Kick HipHop 8			Kick Break 5		●	Wind Chime			Wind Chime		
85	C#5				HipHop Clap 6			Kick Break 6								
86	D5				Snare T8 1			Kick Break 7								
87	D#5				Snare T8 1 H			Hi-Hat Closed Break 3								
88	E5				HipHop Clap 7			Snare Break 4								
89	F5				Tom T8 1			Snare Break 5								
90	F#5				Hi-Hat Closed T8 2			Snare Break 6								
91	G5				Tom T8 2			Snare Break 7								



Kit Name		SFX Kit 1			SFX Kit 2			Pop Latin Kit		
MSB-LSB-PC# (Org:1)		126-0-1			126-0-2			126-0-44		
Note#	MIDI Note	FullName	Key Off (*1)	Alt Grp (*2)	FullName	Key Off	Alt Grp	FullName	Key Off	Alt Grp
13	C#-1							Cajon Low		
14	D-1							Cajon Slap		
15	D#-1							Cajon Tip		
16	E-1							Claves High		
17	F-1							Claves Low		
18	F#-1							Hand Clap		
19	G-1									
20	G#-1							Finger Snap		
21	A-1							Castanet		
22	A#-1							Conga H Tip		
23	B-1							Conga H Heel		
24	C0							Conga H Open		
25	C#0							Conga H Mute		
26	D0							Conga H Slap Open		
27	D#0							Conga H Slap		
28	E0							Conga H Slap Mute		
29	F0							Conga L Tip		
30	F#0							Conga L Heel		
31	G0							Conga L Open		
32	G#0							Conga L Mute		
33	A0							Conga L Slap Open		
34	A#0							Conga L Slap		
35	B0							Conga L Slide		●
36	C1	Cutting Noise 1	●		Phone Call	●		Bongo H Open One Finger		
37	C#1	Cutting Noise 2	●		Door Squeak	●		Bongo H Open Three Finger		
38	D1				Door Slam	●		Bongo H Rim		
39	D#1	String Slap	●		Scratch Cut	●		Bongo H Tip		
40	E1				Scratch Split	●		Bongo H Heel		
41	F1				Wind Chime	●		Bongo H Slap		
42	F#1				Telephone Ring	●		Bongo L Open One Finger		
43	G1							Bongo L Open Three Finger		
44	G#1							Bongo L Rim		
45	A1							Bongo L Tip		
46	A#1							Bongo L Heel		
47	B1							Bongo L Slap		
48	C2							Timbale L		
49	C#2									
50	D2									
51	D#2									
52	E2	Flute Key Click	●		Car Engine Ignition	●		Flute Key Click	●	
53	F2				Car Tires Squeal	●		Paila L		
54	F#2				Car Passing	●		Timbale H		
55	G2				Car Crash	●				
56	G#2				Siren	●				
57	A2				Train	●				
58	A#2				Jet Plane	●				
59	B2				Starship	●		Paila H		
60	C3				Burst	●		Cowbell Top		
61	C#3				Roller Coaster	●		Cowbell 1		
62	D3				Submarine	●		Cowbell 2		
63	D#3							Cowbell 3		
64	E3							Guiro Short		
65	F3							Guiro Long		●
66	F#3							Metal Guiro Short		
67	G3							Metal Guiro Long		●
68	G#3	Shower	●		Laugh	●		Tambourine		
69	A3	Thunder	●		Scream	●		Tambourim Open		
70	A#3	Wind	●		Punch	●		Tambourim Mute		
71	B3	Stream	●		Heart Beat	●		Tambourim Tip		
72	C4	Bubble	●		Foot Steps	●		Maracas		
73	C#4	Feed	●		Feed	●		Shaker		
74	D4							Cabasa		
75	D#4							Cuica Mute		
76	E4							Cuica Open		
77	F4							Cowbell High 1		
78	F#4							Cowbell High 2		
79	G4							Shekere		
80	G#4							Shekere Tone		
81	A4							Triangle Mute		1
82	A#4							Triangle Open		1
83	B4									
84	C5	Dog	●		Machine Gun	●		Wind Chime		
85	C#5	Horse	●		Laser Gun	●		Horse		●
86	D5	Bird Tweet	●		Explosion	●		Bird Tweet		●
87	D#5				Firework	●				
88	E5									
89	F5									
90	F#5	Ghost	●		Ghost	●		Ghost		●
91	G5	Maou	●		Maou	●		Maou		●

Same as SFX Kit 1  
SFX Kit 1と同じ

No Sound  
音は鳴りません