

## Yamaha MOTIF XS Editor Standalone/VST V1.6.4 for Windows Release Notes

---

### Attention

If the MOTIF XS Editor VST under V1.4.0 has already been installed to your computer, uninstall that version of the editor before installing this version.

### Main Revisions and Enhancements

#### V1.6.3 -> V1.6.4

- Fixed a problem in which, when Current in the Auto Sync settings was set to off and synchronized, Cubase would occasionally freeze.

### Known Issues

- After re-installation of the Editor, the Voice name may occasionally not appear on the Media Bay windows of Cubase. If this is the case, execute "Refresh" or "Rescan".
- The Editor may launch in the OFFLINE status or "Port Open Error" may appear when you: 1) select the MOTIF XS Voice via the Media Bay, 2) create the Instrument Track on Cubase, and 3) start the Editor. Even if such a situation occurs, you can use the Editor by clicking the ONLINE/OFFLINE switch to set the status to ONLINE.

### Minimum System Requirements

#### NOTE

- Note that the system requirements may be slightly different from those described below depending on the particular computer.
- Keep in mind that the software is often updated and the system requirements are subject to change. You can check the latest version information of each program and its system requirements at the following website:

<http://download.yamaha.com>

|                 |  |
|-----------------|--|
| OS              | Windows 7 SP1/ Windows 8 (32-bit/64-bit)*                                  |
| DAW Application | Cubase 6 series / Cubase 7 Series  |
| Others          | These system requirements conform to those of the DAW applications and OS. |

\* Operation is not guaranteed in the Windows XP mode on Windows XP mode equipped with Windows 7 or the Boot Camp partition on Mac OS.

### Installing the application:

1. After the downloaded compressed file is properly extracted, double-click a following file.

Install MOTIF XS Editor Standalone\_VST.exe

2. Follow the on-screen instructions to install the software.

### **For users of Windows 8**

#### **Starting the application:**

Once the application is successfully installed, an icon of the application will be in your Windows 8 Start screen. You can start the application by clicking the icon.

#### **NOTE**

If the icon is not listed, right-click an empty area of the Start screen and select "All apps." Then select the application icon from the application list.

#### **Uninstalling the application:**

1. Right-click the application you wish to remove in the Windows 8 Start screen. If it's not listed, right click an empty area of the screen and select "All apps."
2. A check will be placed on the application you selected. Select the "Uninstall" option that appears at the bottom of the screen.

### **Update History**

V1.6.0 -> V1.6.3

- Now supports Cubase 7.5.
- Now supports Windows 8.1.
- Now Cubase5 series are NONcompliant.
- Now Windows XP and Windows Vista are NONcompliant.
- Fixed some minor problems.

V1.5.0 -> V1.6.0

- Now supports Windows 8.
- Now supports a Stand-alone version.
- Solved some minor problems.

V1.4.0 -> V1.5.0

#### **New Features**

- Now supports Cubase 6 series.
- Now Cubase 4 series are NONcompliant.

#### **Fixed Bugs**

- Solved the problem in which the "All" type file of the MOTIF XS (extension: X0A) could not be opened in or imported to the MOTIF XS Editor VST when using the 64 bit version of Cubase.

- Solved the problem in which clicking the [Cancel] button of the Song select window would set the insertion effects of all parts to off when opening the "All" type file of the MOTIF XS (extension: X0A) in the MOTIF XS Editor VST.
- Solved some minor problems.

V1.3.0 -> V1.4.0

#### New Features

- Now supports Cubase 5.5 series.

#### Fixed Bugs

- Solved a problem in which the save operation might fail when you select "Save As..." after selecting "New" from the File menu.
- Solved a problem in which Cubase is forced to quit when you close the Editor window during the Import operation when in the ONLINE status.
- Solved a problem in which Cubase might be forced to quit occasionally when MIDI data is played back with the Editor window open.
- Solved a problem in which the VSTi settings of the Editor might not be restored when opening a Project file of Cubase.
- Solved a problem in which the entire volume might be lowered to 0 when changing the mode from the Editor.
- Solved a problem in which Cubase is forced to quit when clicking the close box of the Editor window repeatedly.
- Minor bug fixes.

V1.2.1 -> V1.3.0

#### New Features

- Now supports Windows 7.
- Now supports Cubase 5.1.
- Now supports Yamaha Steinberg FW Driver V1.5.0.
- Reduced the launching time of the Editor.
- Synchronization between Cubase, Editor and the MOTIF XS instrument has been improved, enabling you to make edits more smoothly and quickly. From this version, both the Editor and MOTIF XS instrument are changed to the Voice mode automatically regardless of the current mode by calling up the VST preset as Voice data from the MediaBay of Cubase or the Editor.

#### **[NOTICE]**

The above operation will erase the currently edited settings of the Editor and MOTIF XS

instrument.

#### Fixed Bugs

- Solved a problem in which a sound would sustain while using the Virtual Keyboard of Cubase.
- Solved a problem in which the Editor would not communicate with the instrument properly when connecting your computer to the instrument using a USB cable, even though the MIDI settings of the Editor Setup were correct.
- Solved a problem in which the Editor could not synchronize with the instrument properly when loading the data that you had saved in the Voice mode of the Editor while the currently selected mode of the instrument was something other than the Voice mode.
- Solved a problem in which Cubase would occasionally quit unexpectedly if MOTIF XS Voices were changed frequently in the MediaBay window of Cubase.
- Solved some minor errors.

V1.2.0 -> V1.2.1

#### New Features

- Compatibility with MOTIF XS6/ MOTIF XS7/ MOTIF XS8 version 1.50 is now enabled.
- It is now possible to store the DAW application file by pressing the [S] key while holding down the [Ctrl] key as a shortcut operation on the Editor.
- The Editor now starts up in Voice mode regardless of the "Startup Mode" setting if the Editor is started from the Instrument Track or the Media Bay. However, when "Auto Start" is set to "on," the Editor starts up in the same mode as the current mode of the MOTIF XS depending on the Current data setting in the Auto Sync Setting.

#### Fixed Bugs

- Improved the system stability of Cubase when changing a MOTIF XS Voice frequently in the Media Bay window of Cubase.
- Minor bug fixes.

---

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2009-2014 Yamaha Corporation All Rights Reserved.