


# About the MIDI Ports settings for the Editor in stand-alone use

Initially, you will need to configure the MIDI Ports settings before using the Editor in stand-alone operation.

When "USB" is selected at the [FW/1394] / [USB] checkboxes and the [Detail] button is set to "Off," select a value such as "MOTIF XF6" (your model) at the top left column. When "USB" is selected and the [Detail] button is set to "On," select Port 1 and Port 4 for both the MIDI In and MIDI Out settings.



Editor setup menu example (USB connection with the MOTIF XF)



When "FW/1394" is selected at the [FW/1394] / [USB] checkboxes, select the MIDI Port of your model (such as MOTIF XF) at the MIDI In / Out column and select the model name at the FW Device column.



Editor setup menu example (FW/1394 connection with the MOTIF XF)

## NOTE

When the Thru checkbox is set to "On," Port1 MIDI In (for the MOTIF-RACK XS: MIDI KB In) -> Port1 MIDI Out function is enabled. This is useful when you wish to sound your instrument from other MIDI devices.



Editor setup menu example (MOTIF-RACK XS)